

Clarke®



TILE CUTTER MODEL NO: CTCM400

PART NO: 3400656

USER INSTRUCTIONS

ORIGINAL INSTRUCTIONS

GC05/25

INTRODUCTION

Thank you for purchasing this CLARKE Tile Cutter.


The CTCM400 tile cutter is ideal for professional and DIY users alike.

Ceramic tiles up to 400mm (16") in length, and 14mm (1/2") thick, may be cut perfectly straight. The CTCM400 has the additional capability of cutting to any angle, accurately, (max. diagonal cut - 400mm).

Please read this leaflet thoroughly before use. This will ensure not only the safety of both yourself and those around you, but also accuracy of operation and long and trouble free service from your tile cutter.

TILE CUTTING

1. Place the tile on the work table with the line to be scored exactly in line with the centre mark on the scale.



- An end stop is provided to ensure the tile is held in a square position. (Ensure the angle gauge is set to zero degrees).

2. Adjust the position of the width guide to accommodate the tile and hold the tile firmly in place with the left hand, as shown.
3. Raise the handle and draw the slide back, past the edge of the tile, then lower the handle so that the tungsten carbide scoring wheel comes into contact with the leading edge of the tile.
4. Apply a firm pressure (not too heavily) down on to the handle whilst pushing forward, smoothly and evenly, in the direction of the arrow, so that the tile is scored along its entire length.
5. Raise the handle and reposition the slide so that the breaker bars are approximately half way along the tile. DO NOT MOVE THE TILE.
6. Pressing down on the handle again will cause the tile to break

It is necessary to score the tile ONCE ONLY.

The tile cutter is provided with an angle gauge so that the tile may be secured at any angle for cutting in a straight line. Simply adjust the angle gauge to the required angle and place the tile so that it is held firmly against the angle gauge guide plate.



GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

A SELECTION FROM THE VAST RANGE OF

Clarke®

QUALITY PRODUCTS



AIR COMPRESSORS
From DIY to industrial, Plus air tools,
spray guns and accessories.

GENERATORS
Prime duty or emergency standby
for business, home and leisure.

POWER WASHERS
Hot and cold, electric and engine
driven - we have what you need

WELDERS
Mig, Arc, Tig and Spot.
From DIY to auto/industrial.

METALWORKING
Drills, grinders and saws for DIY
and professional use.

WOODWORKING
Saws, sanders, lathes, mortisers
and dust extraction.

HYDRAULICS
Cranes, body repair kits,
transmission jacks for all types of
workshop use.

WATER PUMPS
Submersible, electric and engine driven
for DIY, agriculture and industry.

POWERTOOLS
Angle grinders, cordless drill sets,
saws and sanders.

STARTERS/CHARGERS
All sizes for car and commercial use.



PARTS & SERVICE:

0208 988 7400

Parts Enquiries
Parts@clarkeinternational.com

Servicing & Technical Enquiries
Service@clarkeinternational.com

SALES: UK 01992 565333 or Export 00 44 (0)1992 565335

Clarke® INTERNATIONAL Hemnall Street, Epping, Essex CM16 4LG
www.clarkeinternational.com