Clarke®

air



16" LOUVRE VENT

MODEL NO: CL16

PART NO: 3230495

OPERATION & MAINTENANCE INSTRUCTIONS

ORIGINAL INSTRUCTIONS

DL1225

INTRODUCTION

Thank you for purchasing this CLARKE Plate Axial Louvre Vent.

Before attempting to use this product, please read this manual thoroughly and follow the instructions carefully. In doing so you will ensure the safety of yourself and that of others around you, and you can look forward to your purchase giving you long and satisfactory service.

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase. This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended. Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission. This guarantee does not effect your statutory rights.

GENERAL SAFETY WARNINGS

1. Please keep these instructions in a safe place for future reference.
2. **NEVER** carry out any alterations or modifications to this product.
3. **NEVER** carry out any maintenance on this product unless the power has been isolated on the fan unit.
4. **NEVER** insert anything into the louvre grille, unless the power has been isolated on the fan unit.

INSTALLATION

1. Mount the louvre vent securely to an external wall using the 4 outer bolt/screw holes (B) provided in the outer casing, see diagram on page 3. Using the other 4 bolt holes (C) and appropriate length nuts and bolts (not supplied), the louvre vent, can if need be, be aligned and secured to the corresponding sized plate axial exhaust fan and corresponding holes.

NOTE: Corresponding sized plate axial exhaust fans can be purchased from your local CLARKE stockist.

TECHNICAL DATA



Model	A	B	C	D
CL16	500mm	462mm	243mm	10mm

Parts & Service: 020 8988 7400 / E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com

A SELECTION FROM THE VAST RANGE OF

Clarke®

QUALITY PRODUCTS













AIR COMPRESSORS
From DIY to industrial, Plus air tools, spray guns and accessories.

GENERATORS
Prime duty or emergency standby for business, home and leisure.

POWER WASHERS
Hot and cold, electric and engine driven - we have what you need

WELDERS
Mig, Arc, Tig and Spot.
From DIY to auto/industrial.

METALWORKING
Drills, grinders and saws for DIY and professional use.

WOODWORKING
Saws, sanders, lathes, mortisers and dust extraction.

HYDRAULICS
Cranes, body repair kits, transmission jacks for all types of workshop use.

WATER PUMPS
Submersible, electric and engine driven for DIY, agriculture and industry.

POWER TOOLS
Angle grinders, cordless drill sets, saws and sanders.

STARTERS/CHARGERS
All sizes for car and commercial use.

PARTS & SERVICE:
0208 988 7400

Parts Enquiries
Parts@clarkeinternational.com

Servicing & Technical Enquiries
Service@clarkeinternational.com

SALES: UK 01992 565333 or Export 00 44 (0)1992 565335

Clarke® INTERNATIONAL Hemnall Street, Epping, Essex CM16 4LG
www.clarkeinternational.com